```
// Speedometer program adapted by John Crellin May 2025
// original program written by DIY and Digital Railroad
// https://youtu.be/Z OI1jTq 2A?si=aiDp-qr3 nx WhXf
// This version allows for the loco to start either left or right side
// It also converts to scale MPH for HO
// Can be adapted for other scales or to KPH by changing the scale rate
//
// Once you have installed the sensors variable dist1 must be changed to the decimal distance in inches
// example 2.25 is 2 and 1/4 inches distance between sensors
//
// attach an LED with resistor to pin 12
// this LED will go LOW when the first sensor is triggered
// then it will go back HIGH when the speedometer resets
//
// The display is a standard 2x16 LCD display with I2C board attached
//
//
#include <LCD I2C.h>
LCD I2C lcd(0x27,16,2);
unsigned long time1 = 0;
unsigned long time2 = 0;
float dist1 = 2.25; // change this to reflect the correct distance between sensors
float rate1;
float sec1;
float feet1;
float scale1;
int sensor1 = A0;
int sensor2 = A1;
unsigned long startmillis=0;
unsigned long endmillis=0;
void setup(){
 pinMode(12,OUTPUT);
 digitalWrite(12, HIGH);
 lcd.begin();
 lcd.clear();
 lcd.backlight();
 lcd.setCursor(2,0);
 lcd.print("SPEEDOMETER");
 lcd.setCursor(4,1);
```

```
lcd.print("Startup");
 delay(1000);
 lcd.setCursor(4,1);
 lcd.print(" Ready ");
}
enum COUNTSTATES
{
 ST_OFF,
 ST_LEFT,
 ST_RIGHT,
 ST_DONE,
 ST_RESET,
};
COUNTSTATES countState=ST_OFF;
void loop (){
 int value1=analogRead(sensor1);
 int value2=analogRead(sensor2);
 switch(countState)
{
 case ST_OFF:
 countoff(value1,value2);
 break;
 case ST_LEFT:
 countleft(value1,value2);
 break;
 case ST_RIGHT:
 countright(value1,value2);
 break;
 case ST DONE:
 countdone(value1,value2);
 break;
 case ST_RESET:
 countreset(value1,value2);
 break;
}
}
void countoff(int value1, int value2){
 if (value1<500){
 startmillis=(millis());
```

```
countState=ST_RIGHT;
 }
 if (value2<500){
 startmillis=(millis());
 countState=ST LEFT;
 }
}
void countleft(int value1, int value2){
 if (value1<500){
  endmillis=(millis());
  countState=ST_DONE;
 digitalWrite(12, LOW);
}
void countright(int value1, int value2){
 if (value2<500){
  endmillis=(millis());
  countState=ST_DONE;
 }
 digitalWrite(12, LOW);
}
void countdone(int value1, int value2){
 time1=(endmillis-startmillis);
 sec1 = time1/1000.0;
 feet1 = dist1/12.0;
 rate1 = feet1/sec1;
 scale1 = rate1*59.31; //change the 59.31 to change scales or units
 lcd.clear();
 lcd.setCursor(0,0);
 lcd.print("HO scale speed");
 lcd.setCursor(3,1);
 lcd.print(scale1);
 lcd.print(" mph");
 delay(5000);
 countState=ST RESET;
}
void countreset(int value1, int value2){
 lcd.clear();
```

```
lcd.setCursor(2,0);
lcd.print("RESETTING");
digitalWrite(12, HIGH);
delay(500);
lcd.clear();
lcd.setCursor(2,0);
lcd.print("SPEEDOMETER");
lcd.setCursor(5,1);
lcd.print("Ready");
countState=ST_OFF;
}
```